

## Meeting Point Assembly Sheet

### LIST OF COMPONENTS:-

1	TOP
2	TABLE PLATES
2	TABLE LEGS
10	10 X $\frac{3}{4}$ PAN POZI
2	10mm BOLT
1	KD PACK OF LINKING BRACKETS/M6 MUSHROOM BLK

1. Remove the two 8 x  $\frac{1}{2}$  csk screws from each packing piece (dispose of screws and packing pieces.)
2. Screw table plates onto underside of top using 10 x  $\frac{3}{4}$  pan pozi screws into 3mm holes provided, ensuring you first position 10mm bolt now located in the table plates.
3. Screw table legs onto 10mm bolt now located in table plate.
4. Attach top to linking brackets located on the end of cant/slab ends on desk.