

LP/REC 800/600 Assembly Sheet

LIST OF COMPONENTS: -

REC800

Top x 1
Leg1 x 1
Leg2 x 1 (Red dot)
Leg3 x 1 (Green dot)
M6 Bolt x 8
M8 x 22 Hexagon Foot x 5
Minifix Cover x 12
Minifix Chipfast bolt x 4

REC600

Top x 1
Leg1 x 1
Leg2 x 1 (Red dot)
Leg3 x 1 (Green dot)
M6 Bolt x 6
M8 x 22 Hexagon Foot x 5
Minifix Cover x 10
Minifix Chipfast bolt x 4

- 1.Screw M6 bolts into brass spreading dowels of top
- 2.Screw M8 X 22 hex foot into threaded inserts on all legs
- 3.Into leg 1 screw minifix chipfast bolts (2 on each face)
- 4.Locate leg 2 + 3 onto minifix chipfast bolts on leg 1, ensuring all minifix cams face same direction
- 5.Locate all legs onto top and tighten all minifix cams