

ASSEMBLY SHEET FOR ATTACHING SYSTEM PEDESTAL

1. Workstation needs to be fully assembled and turned onto its top.
2. Screw 6 x M6 minifix bolts into top/crossrail
3. Knock 2 x nylon spreading dowels into 5mm holes provided on modesty.
4. Remove drawers and locate pedestal over M6 minifix bolts of top/crossrail and tighten up.
5. Screw 8 x 1 1/2 csk through 5mm hole provided on pedestal back into nylon spreading dowels you have located into modesty. (DO NOT OVER TIGHTEN)
6. Turn desk over, screw handles on drawers and locate drawers back into pedestal.

