

Overhang Top with Desk High Pedestal Assembly Sheet

LIST OF COMPONENTS: -

1	TOP
1	DESK HIGH PEDESTAL
1	LINKING BRACKET SCREWPACK

- 1.Remove the one 8 x 1 ½ csk screws from each packing piece (dispose of screws, packing pieces and packaging materials only after product has been assembled and inspected.)
- 2.Remove top drawer + second drawer from pedestal, undo minifix cams 3 in each side and remove top.
- 3.Take minifix bolts M6 out of desk high top and locate into brass spreading dowels on overhang top.(If attaching a system pedestal use the first + third row of 3 brass spreading dowels from curved edge,use first + second row of 3 if attaching contract pedestal.)
- 4.Place overhang top onto desk high pedestal and tighten minifix cams.
- 5.Attach top to linking brackets located on the end of cant/slab ends on desk.