

## GALAXY PLUS WORKSTATION INSTRUCTION LEAFLET

- Remove the Metal crossrail in its current location and relocate to the other 3mm pilot holes provided.(using the 8 x 11/2 csk screws)
- On each pedestal side screw **One** chipfast bolt into the 5mm hole provided and knock a dowel into the 8mm holes beside it .  
Locate the pedestal sides into the cams that are already located in the top and tighten up the cams closest to the rail only.
- Locate the MDF rail between the two pedestal sides and tighten up the minifix cams.
- Screw **Four** chipfast bolts per pedestal into the holes provided in the modesty/back panel.  
Be aware of which end the pedestal is located.  
(If not attaching pedestal use holes plugs provided to cover 5mm holes in modesty)  
Locate the modesty spigots into the cams of the top, as you do so slightly lift the back edge of the pedestal(s) and locate the chipfast bolts of the modesty into the minifix cams of the pedestals.  
Tighten up all cams and minifix cams.
- Align the holes in the end frame with the holes in the modesty and crossrail.  
Attach the **Three** 7mm x 60mm chipfast to the modesty and the **One** M6 x 60mm bolt to the crossrail

**If attaching a linking option you will need to read the instruction leaflet of what you are linking first.  
This will help make the installation as smooth as possible**