

GALAXY PLUS 90° LINK UNIT INSTRUCTION LEAFLET

- Locate the **Three** spigots of the modesty into the cams of the top, ensuring the 3mm holes provided in the modesty face towards the pointed end of the top.
- Undo the M6 x 60mm bolt already located into the crossrail of the desk you are attaching to, and attach the small 90 degree bracket over.
- Undo **the top** 7mm x 60mm chipfast bolt in the modesty of each desk you are attaching the link unit to, and attach the big 90 degree bracket over.
- Loosen **the bottom** 7mm x 60mm chipfast bolts in the modesty of each desk you are attaching the link unit to, just enough to slide the 45 degree bracket over.
When the modesty brackets are attached to the desk end frame the brackets should follow the intended angle of the modesty.
- Slide the top/modesty onto the brackets you have already located. Once you are happy with the position screw **Three** 8 x 5/8 pozi flange screws into the 3mm holes provided in the top through the holes in the brackets and **Two** 8 x 5/8 pozi flange screws into the modesty.