DH.Mobile.Kit Instruction Leaflet

Stage One

• Remove the two bottom drawers from the unit

Stage Two

- Screw the Nickel Insert into the base from the inside of the unit (ensuring they do not spin).
- Lay the unit on its back.

Stage Three

- Screw the castor bolt complete with the washer into the Nickel Insert from the underneath of the unit.
- Push the Castor onto the Castor bolt until it snaps into position.

Instruction Leaflet No 025