

# **HANDLES INSTRUCTION LEAFLET**

## **TOOLS NEEDED**

Drill  
5mm drill bit  
Phillips Screw driver

- Lay packing piece provided on a level surface.
- Position holes part drilled in the internal face of the drawer front for the handle directly on top of the packing piece.
- Leaning down on drawer drill hole through drawer front in the pilot holes already part drilled.

(Holes are pre-drilled to 14mm deep so you will only need to go another 5mm to break out the other side)

Please ensure your fingers or any other part of your body are not in line With the hole you are drilling through.

- Screw handle into position through the holes you have just drilled.

**Repeat stages for other drawers**

**If under 16 years old please ask for parental consent before assembling unit**