

# **LEE AND PLUMPTON LTD**

## **INSTRUCTION LEAFLET FOR TAMBOUR SLIDING FRAME**

**IF YOU WISH TO FIT TWO SLIDING FRAMES YOU NEED TO POSITION THE RUNNERS AT THE 7<sup>TH</sup> SLOT FROM THE TOP OF THE UNIT & THE 16<sup>TH</sup> FROM THE BOTTOM OF THE UNIT.**

**BEFORE YOU ATTACH THE SLIDING FRAME TO THE RUNNERS YOU NEED TO LOCATE THE METAL 219mm ROD TO THE BLACK CLIPS ON THE RIGHT HAND RUNNERS.**