

No. 088 A/0949 Rev C



Important Information

Safety Guide

- Apply manual handling guidelines when building this item.
- Only use component fixings supplied with this item.

Recommendations

• Build product on a flat surface.

Parts Required



GT50 Castor Black Code: A/0571 Quantity = 4



M8 50mm Castor BoltCode: A/0572 Quantity = 4



Castor Bolt Washer BZP
Code: A/0573 Quantity = 4





M8 x 24mm Nickel Insert Code: A/0628 Quantity = 4 Located in pedestal base

Tools needed



12mm Spanner Quantity = 1

Ascend Pedestal Assembly Instructions

- 1. Turn the pedestal upside down.
- Place washer, part C, on to Castor Bolt, part B.
- 3. Screw part **B** into part **D** located in the Pedestal base. Tighten with a Spanner.
- 4. Push part **B** into part **A** until the castor clicks into place and has been secured.
- 5. Turn the item upright
- 6. The item is now complete.

