





Instructions for changing Front Crank from Right Hand to Left Hand.




Comes as standard to fit to the right hand side of the desk.



Un-tighten the nuts and remove large plate as shown.



Place large plate on opposite side to which you took it off, drop bolts through. Turn unit over carefully and tighten bolts with the nuts you removed earlier.



Crank is now ready to use on the left hand side of the desk.